

Review the following instructions for the installation of our Bar Linear Concealed Mud-In Frame (DABLJ/DABLDJ/DABLRJ/DABLDRJ).

Instructions:

1. If the bar linear has a removable core (DABLRJ/DABLDRJ), remove the core from frame. If not, proceed directly to **Step 2**.
2. Clean and degrease the tapered border and flange to ensure no residue, debris or oil is on the surface.
3. Install the frame to drywall using the drywall screw provided.
4. Apply a bonding agent over the surface of the flange, and allow to dry per the manufacturer's instructions.
5. Apply a coat of drywall compound onto grille flange and extend the compound 3" onto drywall.
6. Embed 4" wide mesh or paper tape into joint compound. Add a second layer of joint compound atop the tape and smooth.
7. Apply a minimum two coats of finishing compound, ensuring to finish over the inside edge of flange. Let each coat dry completely before sanding smooth.
8. Apply your paint or finish coat. Allow finish coat to dry completely.
9. If the bar linear has a removable core (DABLRJ/DABLDRJ), install the core back into the frame.

