

Review the following instructions for the installation of the Concealed Bracket (-C) mounting method used in our Bar Linear (DABL) products.

Before Installation: Determine all Duct Mounted Bracket positions.

Instructions:

1. Place grille in opening and center it to your desired position. Lift the grille until you can mark the Frame Mounted Brackets hole positions on the face of opening.
2. Measure the distance from the backside of the flange to the end of the frame. Add 1/2" to this measurement. This will be the depth of Duct Mounted Bracket. Measuring from the face of your opening, mark the depth inside the opening at each location marked in **Step 1**.
3. Align the center of Duct Mounted Bracket to the mark from **Step 1**. Align the bottom of bracket to the mark from **Step 2**. Using the appropriate screw (not provided) secure the Duct Mounted Bracket to side wall ①. Repeat this step for all the remaining brackets.
4. Place grille in opening. Through the face of the grille, feed #6 x 2" screw through the Frame Mounted Bracket. Thread through the screw holes in Duct Mounted Bracket ②. Tighten until grille pulls securely against face of opening.

